

 $HD\ Heating\ strongly\ recommend\ that\ pipework\ isn't\ installed\ (or\ existing\ pipework\ modified)\ until\ the\ towel\ warmer\ is\ installed\ in\ its\ final\ location.$